




CN1	
○	○
○	○
○	○
○	○
○	○
○	○
○	○
○	○
○	○
○	○
○	○
○	○

- 1 MIDI IN (4P)
- 2 MIDI IN (5P)
- 3 MIDI OUT (4P)
- 4 MIDI OUT (5P)
- 5 UNDEF INPUT
- 6 POWER-LED
- 7 AUDIO OUT
- 8 GND
- 9 POWER GND
- 10 006P+9V
- 11 DC SW GND
- 12 DC GND
- 13 DC+9V

CN2	
A1 D0	○ ○
A2 D2	○ ○
A3 D4	○ ○
A4 D6	○ ○
A5 A0	○ ○
A6 VCC	○ ○
A7 GND	○ ○
B1 D1	○ ○
B2 D3	○ ○
B3 D5	○ ○
B4 D7	○ ○
B5 -CS/-WR	○ ○
B6 4M	○ ○
B7 GND	○ ○

